



## HOW TO UPGRADE FIRMWARE


- 1 Connect the machine to your computer using a USB cable.



- 2 Turn on the POWER SW while pressing [ENTER] key on the machine.




- 3 [UPGRADE FIRMWARE?] message is displayed. Press [ENTER] key for ready to receive data. [WAITING] message will be displayed.




- 3 Start DROPOUT.exe. Open the Print Setup dialog from the File menu. Then, select Roland MDX-540 and click [OK].



**4** Click [Add] and select the firmware file.



**5** Click [Output].  
Dropout.exe sends the firmware to the machine.  
[COMPLETED] message will be displayed when upgrade is completed.



**6** Turn off the POWER SW.

