

What to Do If...

The SETUP LED and CARTRIDGE HOLDER LEDs are flashing

The machine may be malfunctioning. The SETUP LED and CARTRIDGE HOLDER LEDs flash when a fatal error occurs. When this happens, all operation except for switching off the main power becomes impossible. Switch off the main power, then switch it on again. If this does not correct the problem, then check the flashing LEDs and contact your authorized Roland DG Corp. dealer or service center.

Disclaimer: All of the information contained in this document is based on the information available at the time of its creation. In no event will Roland DGA Corporation be liable to you for any damages, including damages for loss of business profits, business interruption, loss of business information and the like arising out of the use of or inability to use these materials.