



### How to Unpack the MPX-50

The packings will be needed if you must repackage the product. Please do not throw them away.


1 Take the accessories out of the carton.



2 Take the unit out of the carton.



3 Remove the packing material and screw.



### How to Repack the MPX-50

Repack the MPX-50 in reverse order of unpacking procedure.


R2-000329

Remove the packing material


### How to Unpack the MPX-50

The packings will be needed if you must repackage the product. Please do not throw them away.


1 Take the accessories out of the carton.



2 Take the unit out of the carton.



3 and screw.



### How to Repack the MPX-50

Repack the MPX-50 in reverse order of unpacking procedure.

R2-000329